



Muscle Cleaner

When you want spray and wipe jobs done right the first time, use Buckeye Eco Muscle Cleaner. Buckeye Eco Muscle Cleaner quickly liquefies and lifts soils for easy removal without hazardous ingredients. Buckeye Eco Muscle Cleaner removes graffiti, ball-point ink, permanent marker, crayon, pencil, black heel marks, food soils, grease, oil, dyes and most stains. With Buckeye Eco Muscle Cleaner, there's no rinsing

Buckeye Eco Muscle Cleaner cleans desktops, lockers, chairs, plastic,* Formica®, vinyl, and any nonporous surface.

* Note: Buckeye Eco Muscle Cleaner may be harmful to some plastics. Test on a small hidden area before use.

Directions for

Connecting 1.25 L Bags to Eco Unit

1. Remove 1.25 L bag from carton.
2. Unlock Eco unit product compartment by turning key to the right.
3. Align Eco unit connector cap lugs with 1.25 L bag metering plug channels. Rotate clockwise to lock in place.
4. Fit 1.25 L bag neatly into product compartment with hose barb pointed downward.
**Ensure chemical line is not pinched.*
5. Close and lock Eco unit product compartment.

Dispensing Diluted Product into 32 oz. Trigger Spray Bottle

1. Use appropriate 32 oz. trigger spray bottle, and slide up over 5-inch discharge hose.
2. Push back lever to dispense diluted product.
3. Once trigger spray bottle is filled (approximately 2 inches from

1.25 L Bag Yield

20 oz./gal. (1:6) makes 2 end-use gallons, which is equivalent to:



Each 4x1 case makes 32 end-use