



# Suma<sup>®</sup> Unison Brite

Liquid acidic rinse aid

# Description

Suma Unison Brite A1 is a concentrated low foam machine rinse additive with scale control properties.

## Key properties

Suma Unison Brite A1 is a concentrated acid rinse additive. It has been specially formulated for use in a wide range of ware washing machines. The product contains a blend of low foam surfactants for rapid and streak free drying and to control foaming in the dishwasher. It also contains scale control agents to keep the machine free from scale in medium hard and hard water conditions.

A special ingredient makes the product suitable for use on soft metals. Suma Unison Brite A1 is effectively dosed with the Diversey Care Unison system, which combines excellent performance, safety and convenience.

## **Benefits**

- Ensures quick drying
- Gives streak and spot-free results
- Highly concentrated gives economy in use
- Convenient pack is easy to handle with less plastic waste
- No contact with chemicals due to innovative packaging design
- Compatible with soft metals

## Use instructions

Suma Unison Brite A1 is automatically dosed into the final rinse water of ware washing machines at a minimum recommended dosing of 0.2 ml/l\* at temperatures of 70-80°C using Diversey Care Unison automatic dispensing equipment.

Actual dosage will depend on site conditions (water hardness, degree of soiling, procedures).

## Technical data

Appearance	clear yellow liquid
pH (neat)	2
Relative density (20°C)	1.04
<b>T</b> ( () () () () () () () () () () () () ()	

These figures are typical values and should not be interpreted as specifications.

#### Safe handling and storage information

Full guidance on the handling and disposal of this product is provided in a separate Safety Data Sheet. Store in original container. Avoid extremes of temperature.

#### Product compatibility

Under recommended conditions of use, Suma Unison Brite A1 is suitable for use on most materials commonly encountered in the kitchen.

\*This dosage is according to optimal conditions, recommendations may vary, please consult with your Diversey Care representative for directions.

